Instruments (Continued) Measurement of lap time







SET button

- 1 Switch the display to the lap time mode.
- 2 Press SET button or start/lap button then start measuring.

While measuring 1 lap



3 Press start/lap button at each lap. In completion of 1 lap



In completion of 21 laps



- 4 Press SET button to end the measurement.
 - ➤ During the measurement, switching to other modes is not available.