Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ▶ P. 54

| Tires and wheels | Check the air pressure (⇒ P. 66), examine tread for wear and damage (⇒ P. 66), and check the wheels for damage. |
|------------------|--|
| Fluid levels | Check the engine oil level (♠ P. 76), engine coolant level (♠ P. 80), and brake fluid level (♠ P. 82). |
| Lights | Check that the headlight, position light, brake light, taillight, turn signals and license plate light are working properly. |
| Controls | Check the freeplay of the clutch lever (→ P. 90) and throttle grip (→ P. 93). |
| Drive chain | Check the slack (♠ P. 86), adjust the slack (♠ P. 87), and lubricate (♠ P. 65) as needed. |
| Fuses | Check that you have a full supply of spare fuses. |
| Nuts & bolts | Check the major nuts and bolts, and tighten as needed. |