

Troubleshooting

Engine Will Not Start	P. 82	Other Warning Indications	P. 85
Overheating (Segment H flashes in coolant temperature gauge)	P. 83	Fuel Gauge Failure Indication.....	P. 85
Warning Indicators on or Flashing	P. 84	Coolant temperature Gauge Failure Indication	P. 85
PGM-FI (Programmed Fuel Injection)		Tire Puncture	P. 86
Malfunction Indicator Lamp (MIL).....	P. 84	Electrical Trouble	P. 93
ABS (Anti-lock Brake System) Indicator (CBR300RA only).....	P. 84	Battery Goes Dead	P. 93
		Burned-out Light Bulb	P. 93
		Blown Fuse.....	P. 97