


Instruments *(Continued)*

Odometer [TOTAL] & Tripmeter [TRIP A/B] display

The **3** (up) or the **4** (down) button selects the odometer, the tripmeter A and tripmeter B when this display is selected.



Odometer

Total distance ridden. When "-----" is displayed, go to your dealer for service.

Tripmeter A/B

Distance ridden since tripmeter was reset.

When "-----" is displayed, go to your dealer for service.

To reset the tripmeter: (P37)