


Instruments (Continued)

DTC


You can check for a current problem with the PGM-FI system.

If your vehicle has problem, DTC index is displayed.

Reduce speed and have your vehicle inspected by your dealer as soon as possible.



- 1 Select [DTC], and then press the **ENT** switch.



- 2 Return to the riding information, previous screen or Home screen. **↶ P.38**
You can also perform the above settings by using the touch screen.