

# Crankcase Breather


---

Refer to *Safety Precautions* on [page 43](#).

Service more frequently if your motorcycle is ridden in the rain or often at full throttle.

If the drain tube overflows, the air filter may become contaminated with engine oil causing poor engine performance.

LEFT SIDE



(1) crankcase breather tube

- Drain the deposits into a suitable container by pinching the crankcase breather tube (1).