

ADJUSTMENTS FOR COMPETITION ...105	TIPS137	INDEX160
Front Suspension Adjustments.....106	Transporting Your Motorcycle.....138	
Front Suspension Air Pressure.....106	Storing Your Honda.....139	QUICK REFERENCE
Front Suspension Damping106	Preparation for Storage.....139	
Fork springs107	Removal from Storage.....139	
Front Suspension Disassembly.....108	You & the Environment140	
Damper Oil Change111	Troubleshooting.....141	
Fork Assembly114		
Rear Suspension Adjustments.....121	TECHNICAL INFORMATION143	
Rear Suspension Spring Pre-Load.....121	Vehicle Identification144	
Rear Suspension Damping.....122	Serial Numbers144	
Rear Suspension Race Sag123	Specifications145	
Suspension Adjustments for Track	Torque Specifications.....146	
Conditions125	Nuts, Bolts, Fasteners146	
Suspension Adjustment Guidelines.....126	Oxygenated Fuels.....149	
Tuning Tips129	Competition Logbook150	
Spark Plug Reading129	Optional Parts List152	
Steering Damper Adjustment130	Spare Parts & Equipment.....153	
Steering Damper Damping130	Spare Parts153	
Steering Damper Adjustment Guidelines.....131	General Tools.....153	
Chassis Adjustments.....132	Honda Special Tools153	
Rear End132	Chemical Products153	
Fork Height/Angle132	Other Products153	
Wheelbase132	Wiring Diagram.....154	
Gearing133		
Tire Selection for Track Conditions.....134	CONSUMER INFORMATION155	
Personal Fit Adjustments135	Authorized Manuals156	
Control Positioning.....135	Contacting Honda.....157	
Handlebar Position, Width & Shape.....135	Your Honda Dealer.....158	
	The Honda Rider's Club (USA only)159	