

Contents

MOTORCYCLE SAFETY	1
Important Safety Information	2
Important Safety Precautions	2
Accessories & Modifications	3
Safety Labels	4
INSTRUMENTS & CONTROLS	5
Operation Component Locations	6
MIL (Malfunction Indicator Lamp)	7
MIL Blink Pattern	7
Current DTC/Freeze DTC	7
Circuit Inspection	8
DTC Index	9
Engine Mode & Launch Control System Indicator ...	10
Engine Mode Indicator.....	10
Launch Control System Indicator	10
BEFORE RIDING.....	11
Are You Ready to Ride?	12
Is Your Motorcycle Ready to Ride?	13
Pre-ride Inspection	13
BASIC OPERATING INSTRUCTIONS	15
Safe Riding Precautions	16
Side Stand (CRF250RX).....	16
Starting & Stopping the Engine	17
Fast Idle Knob	17
Preparation	17
Starting Procedure	17
How to Stop the Engine	18
Parking (CRF250RX)	19
Break-in Guidelines	20

SERVICING YOUR HONDA	21
<i>Before You Service Your Honda</i>	
The Importance of Maintenance	22
Maintenance Safety	23
Important Safety Precautions.....	23
Maintenance Schedule	24
General Competition Maintenance	26
Before & After Competition Maintenance	30
Between Motos (CRF250R)/Races (CRF250RX) & Practice Maintenance	30
After Competition Maintenance	31
<i>Service Preparations</i>	
Maintenance Component Locations	32
Seat	33
Fuel Tank (CRF250R)	34
Fuel Tank (CRF250RX)	37
Subframe	40
<i>Service Procedures</i>	
<i>Fluids & Filters</i>	
Fuel System (CRF250R)	44
Fuel System (CRF250RX)	54
Engine Oil	64
Coolant	68
Air Cleaner	70
Crankcase Breather	72
<i>Engine</i>	
Throttle	73
Engine Idle Speed	75
Clutch System	76
Spark Plug	81
Valve Clearance	82
Piston/Piston Rings/Piston Pin	93

<u>Chassis</u>	
Suspension	102
Brakes	119
Wheels	123
Tires & Tubes	124
Side Stand (CRF250RX)	126
Drive Chain	127
Exhaust Pipe/Muffler	131
Additional Maintenance Procedures	135
<u>Electrical</u>	
Battery	137
Appearance Care	139