

Contents

MOTORCYCLE SAFETY..... 1	BASIC OPERATING INSTRUCTIONS.....23	<i>Service Procedures</i>
Important Safety Information 2	Basic Operating Instructions 24	<u>Fluids & Filters</u>
Important Safety Precautions 2	Safe Riding Precautions 24	Fuel System 60
Accessories & Modifications 3	Carbon Monoxide Hazard..... 24	Fuel 60
Accessories & Modifications 3	Starting & Stopping the Engine 25	Refueling Procedure 60
Off-Road Safety 4	Fast Idle Knob..... 25	Fuel Line Inspection..... 61
Off-Road Safety 4	Preparation 25	Fuel Line Replacement..... 61
Safety Labels 5	Starting Procedure..... 25	Fuel Pump Filter Replacement 63
INSTRUMENTS & CONTROLS..... 7	Bank Angle Sensor Ignition Cut-off System..26	Fuel Pressure Increasing..... 68
Operation Component Locations 8	How to Stop the Engine 26	Engine Oil 69
Indicators & Displays 9	Shifting Gears 27	Oil Recommendation..... 69
Multi-function Display 10	Braking 28	Checking & Adding Oil 70
Speedometer 12	Parking 29	Changing Engine Oil & Filter 70
Odometer/Tripmeter A & B 12	Theft-prevention Tips 29	Coolant 72
Fuel Mileage Meter 12	Break-in Guidelines 30	Coolant Recommendation 72
Digital Clock Setting 13	SERVICING YOUR HONDA31	Checking & Adding Coolant..... 72
Backlight Brightness Adjustment..... 13	The Importance of Maintenance 32	Cooling System Inspection..... 73
Changing the Speed and Mileage Unit..... 14	Maintenance Safety 33	Coolant Replacement 73
Changing the Fuel Mileage Unit 14	Important Safety Precautions..... 33	Cooling System Bleed Air..... 74
Controls & Features 15	Periodic Maintenance 34	Air Cleaner 75
Ignition Switch 15	Maintenance Schedule 35	Cleaning..... 75
Start Button 15	Maintenance Record (On-Road Use Only) 38	Crankcase Breather 77
Engine Stop Switch 15	General Competition Maintenance	Draining..... 77
Headlight Dimmer Switch..... 15	(Off-Road Use Only) 39	<u>Engine</u>
Passing Light Control Switch..... 15	Before & After Competition Maintenance	Throttle 78
Turn Signal Switch..... 15	(Off-Road Use Only) 43	Throttle Freeplay 78
Horn Button..... 15	Between Races & Practice Maintenance 43	Throttle Inspection 79
BEFORE RIDING..... 17	After Competition Maintenance 44	Throttle Cable Lubrication 79
Are You Ready to Ride? 18	<i>Service Preparations</i>	Engine Idle Speed 80
Always carry this manual and tool kit..... 18	Maintenance Component Locations 45	Idle Speed Adjustment 80
Protective Apparel..... 18	Seat 46	Clutch System 81
Rider Training 18	Side Cover 47	Clutch Lever Freeplay 81
Is Your Motorcycle Ready to Ride? 19	Fuel Tank 48	Other Inspections..... 82
Pre-ride Inspection 19	Subframe 52	Clutch Operation 82
Load Limits & Guidelines 21		Clutch Cable Lubrication 82
Loading..... 21		Clutch Disc/Plate Removal 83
Load Limits 21		Clutch Disc/Plate/Spring Inspection 84
Loading Guidelines 21		Clutch Disc/Plate Installation..... 84