

# Index

---

side stand indicator .....	15, 19
spark knock .....	172
spark plugs .....	190
specifications .....	254
speedometer .....	15, 16
stand, side .....	208
start/reverse button .....	37
starting,	
engine .....	72
troubleshooting .....	227
steering lock .....	87
stop switch, engine .....	36
stopping engine .....	73
storage,	
motorcycle .....	220
owner's manual .....	165
suspension,	
rear spring pre-load .....	193
switch,	
audio control .....	38, 101
cruise control .....	37, 92
engine stop .....	36
hazard .....	39
headlight dimmer .....	38
ignition .....	35
rear suspension spring pre-load adjustment .....	41, 193
reverse .....	37, 76
turn signal .....	38

<b>T</b>
----------

tachometer .....	15, 16
theft-prevention tips .....	89
tires,	
air pressure .....	202
flat .....	230
replacing .....	206
tire pressure monitoring system (TPMS) .....	83
tire pressure monitoring system (TPMS) explanation .....	261
tire pressure monitoring system (TPMS) indicator .....	85