


## Base color mode

The display switches as follows by pressing and holding the SEL button:



When the mode you want to set is appears, release the SEL button.

### **|** User setting mode

You can change the tachometer segment color from the following color.

Default setting is "BLUE".

Color								
WHITE	RED	AMBER	YELLOW	GREEN	AQUA	BLUE	VIOLET	PINK

**To set the color:** ➡ P.36