

Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➤ P. 78

Tires and wheels	Check the air pressure (➤ P. 92), examine tread for wear and damage (➤ P. 92), and check the wheels for damage.
Fluid levels	Check the engine oil level (➤ P. 105), engine coolant level (➤ P. 111), and brake fluid level (➤ P. 113).
Lights	Check that the headlight, position lights, brake light, taillight, license plate light and turn signals are working properly.
Controls	Check the freeplay of the clutch lever (NC750X/XA) (➤ P. 121) and throttle grip (➤ P. 124), Check the front brake lever (➤ P. 128), rear brake pedal and parking brake (NC750XD) (➤ P. 115) operate properly.
Drive chain	Check the slack (➤ P. 117), adjust the slack (➤ P. 118), and lubricate (➤ P. 90) as needed.
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.