

## Final Drive Oil

---

5. Pour the drained oil into a suitable container and dispose of it in an approved manner (page 149 ).

### NOTICE

*Improper disposal of drained fluids is harmful to the environment.*

6. Fill the final drive with the recommended oil:  
**5.4 US oz (160 cm<sup>3</sup>)**  
Make sure the final drive oil level is at the lower edge of the oil filler hole (4).
7. Install the oil filler cap and tighten to the specified torque:  
**9 lbf·ft (12 N·m , 1.2 kgf·m)**