


Instruments

Gear range indicator

Shows proper speed range for each gear.

Speedometer

- This shows your speed in miles (USA) or kilometers (Canada) per hour.



Odometer

- Odometer: Total distance ridden.
USA : Odometer & Tripmeter read in miles
Canada : Odometer & Tripmeter read in kilometers

Tripmeter

- Tripmeter: Distance ridden since you last reset the meter. (Turn the tripmeter reset knob as shown direction to reset to zero (0)).

Tripmeter reset knob

