


Refueling



Do not fill with fuel above the filler neck.

Fuel type: Unleaded gasoline only

Recommended fuel octane number:

Pump Octane Number (PON) 86 or higher.

Tank capacity: 2.77 US gal (10.5 liters)

Reserve capacity: 0.61 US gal (2.3 liters)

Refueling and Fuel Guidelines (P12)

Opening the Fuel Fill Cap

- 1a Open the lock cover, insert the ignition key, and turn it clockwise.

- 1b Turn the fuel fill cap counterclockwise and remove it.

Closing the Fuel Fill Cap

- 1a Install and tighten the fuel fill cap firmly by turning it clockwise until the arrow mark on the cap faces forward.
- 1b Turn the ignition key counterclockwise.
- 1c Remove the ignition key from the cap.

3 WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.