

Front Wheel

HONDA

No. Ref.	Old No.	New No.	Description	Reqd. No.
1	C3105401.1	44701-027-000	Rim, wheel	1
2	C3105401.3	44601-027-000	Hub, front wheel	1
3	C3105401.6	44711-027-000	Tire, wheel	1
4	C3105401.7	44712-027-000	Tube, wheel	1
5	C310501.8	97137-212-161	Spoke A, front	18
6	C3105401.9	97351-212-161	Spoke B, front	18
7	C1005407A	44620-001-010	Collar, distance, front axle	1
8	C3105426	44301-027-000	Axle, front wheel	1
9	C3105501	45100-027-000	Panel, front brake	1
10	C3105502	45131-027-000	Cam, front brake	1
11	C1005504A	45120-001-010	Shoe comp., brake	2
12	C1005506A	45133-001-010	Spring, brake shoe	2
13	C3105508	45410-027-000	Arm, front brake	1
14	C1005526	45461-001-000	Joint, front brake arm	1
15	C1005527	45437-001-000	Spring, front brake arm	1
16	C1005528	45462-001-000	Nut, adj. front brake	1
17	C3106441B	44800-027-020	Gear box comp., speedometer	1
18	C3106442B	44830-027-020	Cable Comp., speedometer	1
19	C3107780	90357-027-000	Castle nut, 10 mm	1
20	C3107942A	91252-027-010	Oil seal, 22357	1
21	GB6202	96100-62020	Ball bearing, 6202	2
22	BH618	92000-06018	Hex. bolt, 6×18	1
23	PC2022	94201-20220	Cotter pin, 2.0×22	1