

COLOR TABLE

When ordering a colored part:

1. Confirm the color code for the required part from the color table according to the part name and color type.
2. Select the corresponding part number from the appropriate PAGE/GRID.
3. Parts marked "X" are unused.
4. "*" = Basic Part Number, no extension (i.e. ZA, ZB).

NSR50R'04 2004

No.	DESCRIPTION	COLOR CODE	NH196	A R E A
		BASE COLOR	Ross white NH196	
		BASIC PART NO.		
1	COWL (UPPER)	64200-NLA-000	●	
2	COWL, L. (LOWER)	64260-NLA-000	●	
3	COWL, R. (LOWER)	64250-NLA-000	●	
4	FENDER, FR.	61100-NLA-000	●	
5	FRAME	50100-NLA-000	●	
6	PLATE, FR. NUMBER	64210-NLA-000	●	
7	TANK, FUEL	17510-GT4-711	●	
8	WHEEL SUB-ASSY., FR.	44650-NLA-000	●	
9	WHEEL SUB-ASSY., RR.	42650-NLA-000	●	