



Parts Catalogue Structure



	(3)	(4)	(5)	(6)	(7)	(9)	(10)	(11)	(12)	(13)
Service Item	F.R.T.	Ref. No.	Part No.	Description				Recpt. No. CIBSNOO NON ROP NON RES RET ROY	Serial No.	Area code
*Headlight Unit.....	.05	1	33101-AWE-601	Headlight Unit "NH-283" Gray	-	-	1	- -	-----	E, MX,
*Bulb Position Light					-	-	1	- -	-----	E
Bulb	.01				-	-	1	- -	-----	R/R
*Bulb Headlight			33101-AWE-612	Headlight Unit "NH-283" Gray	-	-	1	- -	-----	AR, ED, F, G,
				(Caution During Installation)	-	-	1	- -	-----	H, ND, SP,
					-	-	1	- -	-----	SW, ZG
					-	-	1	- -	-----	AR, G, H, ND,
					-	-	1	- -	-----	SW
					-	-	1	- -	-----	ED, IT
					-	-	1	- -	-----	F
					-	-	1	- -	-----	OASD338
			33101-AWE-671	Headlight Unit "NH-1" Black	-	-	1	- -	-----	M
					-	-	1	- -	-----	C/M
					-	-	1	- -	-----	IT
			33101-AWE-691	Headlight Unit	-	-	1	- -	-----	E
			33101-AWE-602	Headlight Unit	-	-	1	- -	2351960-	N/A
					-	-	1	- -	2351713 -	E, MX
					-	-	1	- 1	-----	

- ① **Block number**
 - Address No. is provided (in place of the page No.) to help you refer to the part with the part No. or part name..
- ② **Block number**
- ③ **Service item/Flat rate time**
- ④ **Reference number**
 - Title number marked with the parenthesis or parentheses indicates that it continues from the previous page.
- ⑤ **Part number**
- ⑥ **Description**
- ⑦ **HONDA color code**
- ⑧ **Assemblies**
 - Sections framed with broken lines in the exploded view drawings are available as complete assemblies. (Their individual parts can also be obtained).
- ⑨ **Color description**
- ⑩ **Note**
 - Attention are shown with the parentheses in the part name column.
- ⑪ **Required quantity**
 - Req'd. QTY shown in the parenthesis or parentheses indicates the optional part.
 - Req'd. QTY marked with "N" indicates the optional part that should be selected as needed.
 - Req'd. QTY indicates the number of the part used in the block.
- ⑫ **Serial number**
- ⑬ **Area code**
 - When the area code is blank, it indicates that the part is applicable to all types.
- ⑭ 
 - Parts enclosed within a dotted line  are covered in a different block.
- ⑮ 
 - A hollow arrow  indicates the block No. for the parts enclosed within a dotted line .
- ⑯ 
 - A solid arrow  indicates the block No. the part in question is connected to.