

| ENGINE GROUP                         |                                       |                                                |                                      |
|--------------------------------------|---------------------------------------|------------------------------------------------|--------------------------------------|
| <b>E-14</b><br>RADIATOR<br>          | <b>E-16</b><br>DRIVE FACE<br>         | <b>E-17</b><br>DRIVEN FACE<br>                 | <b>E-19-20</b><br>LEFT CRANKCASE<br> |
| <b>E-17-10</b><br>TRANSMISSION<br>   | <b>E-19-10</b><br>RIGHT CRANKCASE<br> | <b>E-22</b><br>THROTTLE BODY/FUEL INJECTOR<br> |                                      |
| <b>E-20</b><br>CRANKSHAFT/PISTON<br> |                                       |                                                |                                      |