


F - 29

Battery



Bagian yang diservice	F.R.T.	Nomor Petunjuk	Nomor Part	Uraian Part	Jumlah	Nomor Serie	Catatan
BOX, BATTERY	0.2	1	17232-KCJ-660	TRAY COMP., BATTERY	1	IN	
BATTERY	0.2		17232-KCJ-670	TRAY COMP., BATTERY	1	2IN	
CABLE, STARTER MOTOR	0.3	2	17234-KCJ-660	COVER, BATTERY	1		
CABLE, NEGATIVE BATTERY	0.2	3	31500-KW1-902	BATTERY (YB7B-B YUASA)	1		
SWITCH, STARTER MAGNETIC	0.3	4	31502-KCJ-690	TUBE, BATTERY BREATHER	1		
		5	32410-KCJ-660	CABLE, STARTER MOTOR	1		
		6	32601-KCJ-690	CABLE, BATTERY EARTH	1		
		7	35850-KCJ-661	SWITCH ASSY., STARTER MAGNETIC	1		
		8	35856-KCJ-660	RUBBER, MAGNETIC SHOCK	1		
		9	94050-06000	NUT, FLANGE, 6MM	1		
		10	95701-06010-08	BOLT, FLANGE, 6X10	1		
		11	95701-06012-07	BOLT, FLANGE, 6X12	3		