


F-22

Stand

Bequille

Ständer

Estante



BMC8-38

Service item	F.R.T.	Ref. No.	Part No.	Description	Read. No. FT500	Serial No.	Area code
SPRING D., SIDE STAND	0.1	1	50500-MC8-000	STAND COMP., MAIN	1		
BAR COMP., SIDE STAND	0.2	2	50510-413-610	SPRING, MAIN STAND	1		1G,2G
SPRING F., MAIN STAND		3	50520-413-610	SUB SPRING, MAIN STAND	1		1G,2G
STAND COMP., MAIN	0.5	4	50525-471-610	HUUK, MAIN STAND SPRING	1		1G,2G
		5	50525-471-000	SHAFT, MAIN STAND PIVOT	1		
		6	50530-MC8-610	BAR COMP., SIDE STAND	1		
		7	50540-MC8-610	AKM, RR. BRAKE STOPPER	1		
		8	50542-438-000	SUB SPRING, SIDE STAND	1		1G,2G
		9	50548-356-700	RUBBER, STAND	1		
		10	50549-356-700	COLLAR, STAND RUBBER SETTING	1		
		11	50730-471-000	GUIDE, OVERFLOW TUBE	1		
		12	90108-223-000	SCREW, SIDE STAND PIVOT	1		