Tools

Special

Description	Tool number	Applicability
Bearing remover, 12 mm Remover shaft Remover weight	Generic tool 07936–1660120 07741–0010201	Water pump bearing
Water seal driver	07945–KA30000	Water seal
Attachment, 28 x 30 mm	07946–1870100	Water pump bearing
Clutch center holder	07JMB–MN50302	Clutch center lock nut
Fork seal driver set	07947–4630100	Fork oil seal
Fork damper holder	Generic tool	Right fork socket bolt
Fork damper holder	07930–KA50100	Left fork socket bolt
Ball race remover	07948–4630100	Stem bearing race
Steering stem driver	07946–4300000	Stem lower bearing
Bearing driver	07946–KA50000	Swingarm pivot bearing
Bearing remover	07946–MJ00100	Shock link needle bearing
		Swingarm link bearing
Spherical bearing driver	07HMF–KS60100	Shock absorber bearing
Snap ring pliers	07914-SA50001	Master cylinder snap ring
Flywheel holder	89020–NN4–003	Flywheel
Flywheel puller	Generic tool	Flywheel
Compressor attachment	07959–MB10000	Shock absorber spring

Common

Description	Tool number	Applicability
Spoke nipple wrench	07701–0020300	Front spoke nipple
Gear holder	07724–0010100	Primary drive gear bolt
Bearing remover head	07746–0050600	Wheel bearing
Bearing remover shaft	07746–0050100	Wheel bearing
Driver	07749–0010000	Bearing removal/installation
Attachment, 24 x 26 mm	07746–0010700	Swingarm pivot bearing
Attachment, 32 x 35 mm	07746–0010100	Right countershaft bearing
		Left mainshaft bearing
Attachment, 37 x 40 mm	07746–0010200	Left shift drum bearing
Attachment, 42 x 47 mm	07746–0010300	Right mainshaft bearing
		Left countershaft bearing
		Right shift drum bearing
		Wheel bearing
		Ball race
Attachment, 52 x 55 mm	07746–0010400	Crankshaft oil seal
Attachment, 62 x 68 mm	07746–0010500	Left crankshaft bearing
Attachment, 72 x 75 mm	07746–0010600	Right crankshaft bearing
Pilot, 12 mm	07746–0040200	Water pump bearing
Pilot, 17 mm	07746–0040400	Right countershaft bearing
		Left mainshaft bearing
Pilot, 20 mm	07746–0040500	Left countershaft bearing
		Wheel bearing
		Swingarm pivot bearing
Pilot, 22 mm	07746–0041000	Right mainshaft bearing
Pilot, 25 mm	07746–0040600	Right shift drum bearing
Pilot, 30 mm	07746–0040700	Right crankshaft bearing
Pin spanner	07702–0020001	Shock spring adjuster (2 required)
Shock absorber compressor	07GME–0010100	Shock absorber spring