Requisite Service

- Rear fairing removal/installation (page 2-3)
- Battery removal/installation (page 15-4)

	Procedure	Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Speed sensor connector (3P White)	1	
(2)	Fuel pump connector (2P Red)	1	
(3)	Side stand switch connector (3P Green)	1	
(4)	Fuel cut-off relay connector	1	
(5)	Turn signal relay connector	1	
(6)	Ignition control module connector	1	
(7)	Speed sensor/side stand switch wire	1/1	Release from the clip.
(8)	Fuel pump	1	Remove from the sub frame stays.
(9)	Starter relay switch	1	Remove from the stays and release the wire harness from the clamp.
(10)	Wire harness	1	Release from the clips.
(11)	Regulator/rectifier connector	1	
(12)	Brake reservoir hose	1	Release from the clip.
(13)	Wire harness	1	
(14)	Brake hose	1	Release from the clamp.
(15)	Rear master cylinder reservoir	1	NOTE • Keep the reservoir upright to prevent air from entering the hydraulic system.
(16)	Trim clip	2	
(17)	Muffler mounting bolt	1	
(18)	Sub frame bolt/nut (lower)	2/1	
(19)	Sub frame bolt (upper)	2	
(20)	Sub frame assembly	1	
(21)	Fender bolt	4	
(22)	Rear fender	1	