Valve timing is correct when the timing arrows are level with the cylinder head upper edges, and the intake and exhaust timing arrows face opposite each other.

