## Rear Suspension Adjustment Adjustments for Type of Track

Hard-surfaced track	Begin with the standard settings. If the suspension is too stiff/soft, adjust according to the chart below.	
Sand track	Lower the rear end (to improve front wheel stability) by increasing Race Sag (reduce spring pre-load).  Example: – Turn the compression damping adjuster and, especially, rebound damping adjuster to a stiffer setting.  – Increase standard Race Sag (+5 to 10 mm/0.2 to 0.4 in).	
Mud track	track  Adjust to a stiffer position because mud build-up increases your CRF's weight.  Example: — Adjust the compression and rebound damping adjusters to stiffer settings.  — Install the optional stiff spring.  — Reduce standard Race Sag (–5 to 10 mm/0.2 to 0.4 in).	

## Symptoms and Adjustment

- · Always begin with the standard settings.
- Turn the low speed compression and rebound adjusters in one-click increments, and the high speed compression adjuster in 1/12 turn increments at a time. Adjusting two or more clicks or turns at a time may cause you to pass over the best adjustment. Test ride after each adjustment.
- If, after setting, the suspension feels unusual, find the corresponding symptom in the table and test stiffer or softer compression and/or rebound damping adjustments until the correct settings are obtained as described.

	Symptom	Action
Stiff suspension	Suspension feels stiff on small bumps	<ol> <li>Test softer low speed compression adjustment.</li> <li>If it still feels stiff, further test softer low and high speed compression adjustments simultaneously.</li> </ol>
	Suspension feels stiff on large bumps	<ol> <li>Test softer high speed compression adjustment.</li> <li>If it still feels stiff, further test softer low and high speed compression adjustments simultaneously.</li> </ol>
	Entire travel too stiff	<ol> <li>Test softer high and low speed compression adjustments and rebound adjustment simultaneously.</li> <li>If it still feels stiff, replace the spring with a softer spring (optional) and begin with the standard settings to softer settings.</li> </ol>
Soft suspension	Entire travel too soft	<ol> <li>Test stiffer high and low speed compression adjustments simultaneously.</li> <li>If it still feels soft, replace the spring with a stiffer spring (optional) and begin with the standard settings to stiffer setting.</li> </ol>
	Rear end sways	Test stiffer high and low speed compression adjustments and rebound adjustment to stiffer settings simultaneously.
Suspension bottoms	Suspension bottoms at landing after jumping	<ol> <li>Test stiffer high speed compression adjustment.</li> <li>If it still bottoms, test stiffer high and low speed compression adjustments, and replace the spring with a stiffer spring (optional) if necessary.</li> </ol>
	Suspension bottoms after landing	<ol> <li>Test stiffer low speed compression adjustment.</li> <li>If it still bottoms, test stiffer high and low speed compression adjustments, and replace the spring with a stiffer spring (optional) if necessary.</li> </ol>
	Suspension bottoms after end of continuous bumps	<ol> <li>Test softer rebound dumping adjustment.</li> <li>If it still bottoms, test stiffer high and low speed compression adjustments and softer rebound damping adjustment, and replace the spring with a stiffer spring (optional) if necessary.</li> </ol>